
Daily Poolside Slide SPECTRUM Inspection AQUATICS® Checklist

Inspection Information

Facility Name	Inspection by	Date

Inspect slide path to make sure there are no obstructions.

Look for chips, bubbles, or cracks in the gel coat.



Check for caulk that has peeled or worn away.

Tighten any loose fasteners and replace any that are missing.

Check for any excessive or abnormal movement of structural parts.

Check that the water flow amount to the slide is in range.

Visual Inspection of stairs and slide structure.

Make sure signage is placed correctly.

If any of these items are noticed, they must be corrected and repaired before the poolside slide can be opened for use to ensure guest safety.

For detailed information on poolside slide maintenance and cleaning please contact our service department at 800-791-8056.